



# INSTRUCTIONS FOR USE: HIP ARTHROSCOPY BOOTLINERS (#40532SN)



1. Unfold bootliner and have the white DermaProx™ layer facing upwards.


2. Place patient's heel in the middle of the pad so that the notch aligns with patient's calf.

3 AB.



3A. Place strap A (non-velcro side) of middle strap on top of patient's ankle.


3C.



3B. Place strap B (velcro side) of middle strap on top of strap A so the patient's foot is wrapped. Be sure not to overtighten.


3C. Wrap non-velcro side of the pad around the patient's toes.

3D.




3D. Wrap bottom half of pad around the rest of the patients toes and place the velcro on top of the non-velcro side of the pad so that the top of the patient's foot is wrapped. Be sure not to overtighten.

4A.




4A. Wrap non-velcro side of the pad around the patient's calf

4B.



4B. Wrap bottom half of pad around the rest of the patients calf and place the velcro on top of the non-velcro side of the pad so that the patient's foot is wrapped. Be sure not to overtighten.

Final Product



702 Prominence Drive  
Pittsburgh, PA 15068 U.S.A.

Tel: 724.337.5500  
Fax: 724.337.0555



xodusmedical.com  
info@xodusmedical.com

FDA REGISTERED  
ISO 13485 CERTIFIED

xodusmedical.com/eifu

EMERGO EUROPE  
Prinsessegracht 20  
2514 AP The Hague  
The Netherlands